

INSERT (SEMI INSERT) BASIN INSTALLATION INSTRUCTIONS

Important Information

- Prior to Installation it is important to inspect the basin to ensure no damage has occurred in transit. If damage has occurred, or a visible defect exists, do not proceed with installation & advise supplier immediately.
- ECT or your supplier will not be liable for the cost of installation or removal of your basin, and warranty will be voided if damage has occurred during or after installation.
- It is recommended that a licensed tradesperson install the basin.
-

Installation

1. Measure & Mark Cut-Out

- Place the basin upside down on the countertop.
- Trace the outline of the basin.
- Mark a second inner line (approx. 15-20mm inside) for the cut-out.

2. Cut the Countertop

- Drill a starter hole inside the marked area.
- Use a jigsaw to cut along the inner line.
- Smooth edges and remove debris.

3. Test Fit the Basin

- Insert the basin into the cut-out.
- Ensure it sits properly with the rim resting on the countertop.
- Adjust opening if needed.

4. Apply Sealant

- Apply a continuous bead of silicone around the underside of the basin rim.

5. Position the Basin

- Carefully place the basin into the cut-out.
- Press down evenly to ensure full contact with the countertop.

6. Seal & Finish

- Apply additional silicone around the rim edge if required. Smooth for a clean, professional finish.
- Allow to cure (24 hours recommended).