

# Pop-Up Waste Installation Instructions

## Step 1 – Prepare the Basin

1. Ensure the basin waste hole is clean and free of debris.
  2. Check that the pop-up waste kit includes:
    - Waste body with pop-up lid
    - Two silicone seals
    - Brass Lock nut
- 

## Step 2 – Insert the Waste Body

1. Remove the brass nut and lower silicone seal from the body.
  2. Insert the waste body into the basin hole from above with upper silicon seal against the basin.
- 

## Step 3 – Secure from Below

1. From underneath the basin, place the lower silicone seal over the thread against the ceramic surface.
  2. Then screw on the brass lock nut.
  3. Tighten the nut by hand, then use a wrench to secure firmly – **do not overtighten to avoid cracking the basin.**
- 

## Step 4 – Connect to the Trap

1. Align the bottom of the waste body with your basin trap.
  2. Connect and tighten securely.
  3. Ensure all connections are straight and properly sealed.
- 

## Step 5 – Test for Leaks

1. Fill the basin with water and operate the pop-up function.
2. Check all joints underneath for leaks.
3. If leaks occur, apply a thin layer sealant and re-tighten connections as needed.

## Maintenance Tips

**Regular Cleaning:** Unscrew the pop-up lid anticlockwise **when the lid is up**. Rinse off hair, soap residue, and debris. Use a mild detergent and soft cloth to clean — avoid harsh chemicals that may damage the finish.