

BATH SPOUT INSTALLATION INSTRUCTIONS

Important Information

- Not suitable for gravity feed systems.
- All pipework must be thoroughly flushed prior to installation.
- Please check the product before installation, make sure there is no visible damage.

Claim on damage after installation is not accepted.

Installation

1. Check the thread on the nipple has the correct length. Cut to length if required. Also make sure end face is square.
2. Apply thread tape to the thread. Care must be taken that thread tape cannot become dislodged and block the flow regulating device, causing a reduction in water flow.
3. Screw spout onto threaded nipple, continuing until the shoulder contacts the cover plate and the outlet is pointing downwards.
4. Turn on the water and check if there is any leak.