

INSTALLATION INSTRUCTIONS- DOCCIA Shower Head

Note: It is the installer/consumers responsibility to ensure:

- Product is not damaged prior to installation.
- The product has all its components.
- Water Supply Requirements:
If the pressure exceeds 550kpa, an approved pressure limiting device must be installed. If the water temperature exceeds 75°C, an approved tempering valve must be installed.
- Shower may not be suitable for use with gravity-fed water heaters.
- Failure to comply with above may void all warranties.

WATER SUPPLY REQUIREMENTS



Installation Steps

1. Apply Thread Seal Tape

- Wrap **Teflon tape clockwise** around the shower arm thread
- Wrap 5–7 times to ensure a tight seal

2. Insert Washer

- Ensure the **rubber washer** is inside the shower head connector
- This prevents leaks and ensures proper sealing

3. Attach the Shower Head

- Screw the shower head onto the shower arm
- Tighten by hand first
- Use a spanner with a soft cloth to gently tighten (do not overtighten)
- Turn on water slowly
- Check for leaks around the connection
- If leaking: Tighten slightly or Reapply Teflon tape

Important Notes

- Do not overtighten (may damage threads or finish)
- Use a cloth to avoid scratching the surface
- Ensure washer is properly seated before installation

Maintenance Tips

- Clean nozzles regularly to prevent buildup
- Use mild soap only (avoid harsh chemicals)