

## ***UNDERMOUNT BASIN INSTALLATION INSTRUCTIONS***

### **Important Information**

- Prior to Installation it is important to inspect the basin to ensure no damage has occurred in transit. If damage has occurred, or a visible defect exists, do not proceed with installation & advise supplier immediately.
- ECT or your supplier will not be liable for the cost of installation or removal of your basin, and warranty will be voided if damage has occurred during or after installation.
- It is recommended that a licensed tradesperson install the basin.

### **Installation**

#### **1. Measure & Mark Cut-Out**

- Measure the basin opening accurately.
- Mark the cut-out position on the underside or top of the countertop.
- Ensure correct alignment with the tap and waste outlet.

#### **2. Cut the Countertop**

- Cut the hole according to the marked dimensions.
- Smooth and clean all edges to prevent damage.

#### **3. Test Fit the Basin**

- Place the basin under the cut-out.
- Ensure it sits evenly and aligns correctly.
- Adjust if necessary.

#### **4. Apply Sealant**

- Apply a continuous bead of waterproof silicone around the rim of the basin.
- Ensure full coverage to prevent leaks.

#### **5. Fix the Basin**

- Position the basin under the countertop.
- Secure using:
  - Mounting clips (if provided), or
  - Brackets/support frame, or
  - Strong adhesive support
- Hold in place using clamps until fully set. Allow sealant to cure (usually 24 hours).