

Installation Instructions

Shower Curtain (TP SC1212 Kit & TP SC1615 Kit)



① Upper and down hanging rod



② Screw for hanging rod



③ L-shaped wrench



④ Screw for hanging rod and track connection



⑤ Runner



⑥ End cap and mounting bracket



⑦ Mounting screw and anchor



1

Assemble the upper and down hanging rod(1) with screws(2) and L-shaped wrench



2

Put screw(4) in the down hanging rod and then connect the hanging rod and track by screw(4)



3

Put the runner(5) in the track



4

Put the end cap(6) in the track and mount it to the wall



5

Mount the upper hanging rod to the ceiling with screw and anchor(7)