VICTORIA, WB 5644 / WB 5644-3.TH, GLOSS WHITE

Installing the basin.

IMPORTANT INFORMATION

01 Before installation, inspect the basin to make sure no damage has occurred in transit. If damage has occurred, or a visible defect exists, do not proceed with installation and advise your supplier immediately.

02 ECT Global and your supplier are not liable for the cost of installing or removing the basin. The warranty is voided if damage occurs during or after installation.

03 It is recommended that a licensed tradesperson installs the basin.

INSTALLATION

STEP 01

Mark the cut out.

- Place the basin upside down on the countertop.
- Trace the outline of the basin.
- Mark a second inner line (approx. 15 to 20mm inside) for the cut out.

STEP 02

Cut the countertop.

- Drill a starter hole inside the marked area.
- Use a jigsaw to cut along the inner line.
- Smooth the edges and remove debris.

STEP 03

Test fit the basin.

- Insert the basin into the cut out.
- Ensure it sits properly with the rim resting on the countertop.
- Adjust the opening if needed.

STEP 04

Apply sealant.

- Apply a continuous bead of silicone around the underside of the basin rim.

STEP 05

Position the basin.

- Carefully place the basin into the cut out.
- Press down evenly to ensure full contact with the countertop.

STEP 06

Seal and finish.

- Apply additional silicone around the rim edge if required. Smooth for a clean, professional finish.
- Allow to cure (24 hours recommended).

ADDRESS
42 Castro Way, Derrimut VIC 3026

PHONE
(03) 8390 6300

EMAIL
sales@zenmo.com.au

WEBSITE
www.zenmo.com.au