SORRENTO-II, WB 3046, GLOSS WHITE

Installing the basin.

IMPORTANT INFORMATION

01 Before installation, inspect the basin to make sure no damage has occurred in transit. If damage has occurred, or a visible defect exists, do not proceed with installation and advise your supplier immediately.

02 ECT Global and your supplier are not liable for the cost of installing or removing the basin. The warranty is voided if damage occurs during or after installation.

03 It is recommended that a licensed tradesperson installs the basin.

INSTALLATION

STEP 01

Mark and cut.

Use the basin as a guide to mark the benchtop for the tap and waste outlet positions. Cut out the required shape. Allow room for the waste back nut and tapware to be accessible from underneath.

STEP 02

Fit the waste.

Install the waste to the basin. Do not over tighten it, as this puts stress on the basin and may crack it.

STEP 03

Fix the basin.

Place the basin in position and fix it using neutral cure, mildew resistant, sanitary grade silicone. Clean away excess silicone from around the basin.

USE OF EPOXY TWO PART ADHESIVES WILL VOID THE WARRANTY

ADDRESS
42 Castro Way, Derrimut VIC 3026

PHONE
(03) 8390 6300

EMAIL
sales@zenmo.com.au

WEBSITE
www.zenmo.com.au