JESS CARE, SHOWER MIXER

Before you install.

REQUIREMENTS

INSTALLER	Installation must be carried out by a qualified plumber. Keep the certificate of compliance, as it is needed for any warranty claim.
PIPEWORK	Flush all pipes leading to the mixer before installation.
PRESSURE	Test the water pressure and limit it to 500kPa or less. Fit an approved pressure reducing valve if it exceeds 500kPa. Hot and cold water inlet pressures should be equal.
TEMPERATURE	The maximum hot water temperature is 75°C. Fit an approved water tempering valve if the water temperature exceeds this.
ISOLATING TAPS	Fit isolating taps to both the hot and cold inlet connections, in accordance with the national plumbing code AS3500.

150kPa	500kPa	1°C	75°C
Minimum pressure	Maximum pressure	Minimum water temperature	Maximum hot water temperature

FAILURE TO COMPLY WITH ANY OF THE ABOVE WILL VOID ALL WARRANTIES

ADDRESS
42 Castro Way, Derrimut VIC 3026

PHONE
(03) 8390 6300

EMAIL
sales@zenmo.com.au

WEBSITE
www.zenmo.com.au

JESS CARE, SHOWER MIXER

Installing the mixer.

STEP 01

Fix the mixer body

Fix the mixer body onto a suitable mounting plate or noggin in the wall. Secure it using screws through the holes in its base.

STEP 02

Check the connections

When facing the mixer, the hot water inlet connection H is on the left and the cold water inlet connection C is on the right. The mixed water outlet connection points vertically upwards. Check all connections for leaks.

STEP 03

Set the body square

Install the mixer body square to the wall or tile face so the cover plate sits flush. Do not remove the plastic sleeve until installation is complete. This avoids damaging the decorative finish.

STEP 04

Fit the cover plate

Fit the cover plate onto the mixer body after the tiles are on. Make sure the plate sits flush.

STEP 05

Fit the handle

Use an Allen key to loosen the grub screw in the handle and fit the handle on the mixer body. Tighten the grub screw and fit the plug to cover the screw hole.

STEP 06

Turn on the water

Turn on the isolating stop taps and check for leaks.

DO NOT REMOVE THE PLASTIC SLEEVE UNTIL INSTALLATION IS COMPLETE

ADDRESS
42 Castro Way, Derrimut VIC 3026

PHONE
(03) 8390 6300

EMAIL
sales@zenmo.com.au

WEBSITE
www.zenmo.com.au

JESS CARE, SHOWER MIXER

Replacing the cartridge.

STEP 01

Turn off the water

Turn off the hot and cold water supplies at the isolating stop taps.

STEP 02

Remove the handle and cartridge

Carefully remove the screw plug, loosen the grub screw and remove the handle. Unscrew the dress ring on the mixer body, taking care not to damage the finish. Remove the lock nut, then lift out the old cartridge.

STEP 03

Fit the new cartridge

Make sure the inside of the mixer body is clean. Check that the seal is in position in the base of the new cartridge, then fix the new cartridge into the mixer body. Make sure the two lugs on the base of the cartridge fit into the mating holes in the mixer body.

STEP 04

Tighten the lock nut

Screw on the lock nut and tighten it to a torque of 12Nm. Replace the dress ring and tighten it firmly by hand.

STEP 05

Refit the handle

Fit the handle back on the mixer body and fit the plug to cover the screw hole.

STEP 06

Turn on the water

Turn on the isolating stop taps and check operation.

12Nm

Lock nut tightening torque

ADDRESS
42 Castro Way, Derrimut VIC 3026

PHONE
(03) 8390 6300

EMAIL
sales@zenmo.com.au

WEBSITE
www.zenmo.com.au