

## WALL TOP ASSEMBLIES INSTALLATION INSTRUCTIONS

### Important Information

- All pipework must be thoroughly flushed prior to installation.
- Hot and Cold water inlet pressures should be equal.
- Maximum operating pressure at any outlet is 500 kPa.
- Maximum hot water temperature is 80°C.

### Installation

1. Check in-wall depth (A) is less than 13mm. Check seats in recess tap bodies (1) are in good condition and free of foreign materials. Reseat if required.
2. Full open tap spindle (3) in tap head assembly (2). Ensure fibre washer and jumper valve are in position as shown.
3. Screw tap head assembly (2) into recess tap body (1) by hand and tighten using suitable tube spanner.
4. Screw on wall flange (4) and tighten fully by hand against wall/tile. Please take care not to damage the decorative finish.
5. Fit handle assembly as follows:
  - Turn both spindles to the fully closed position.
  - Place retaining nut (6) over spindle (3), with slot facing flange (4).
  - Place retaining clip (7) into groove at bottom of spline in spindle (3).
  - Ensure handle insert (8) is in position in handle (9). Fit handle (9) to spindle (3), position to suit. Push handle (9) firmly down to the bottom internally.
  - Screw retaining nut (6) into handle and tighten using spanner (5) provided.

